



Locks and Bolts

- PVCu and aluminium doors should have multi-locking systems.
 Additional mortice deadlocks and/or key operated throw bolts
 can be fitted to provide additional security and reduce the
 leverage points.
- Always remember to lift multi-locking handles and lock with a key, to prevent burglars reaching in through the letterbox to open the door. Internal letterbox shields also prevent car or house keys being fished through the letterbox.
- Wooden front doors should be solid timber, with a BS 5-lever mortice lock one third of the way up and an automatic deadlocking rim latch one third of the way down.
- Wooden back doors should be solid timber, with a BS 5-lever mortice lock and two mortice rack bolts.
- (5) Hinge bolts should be fitted to outward opening doors.
- Patio doors should have a minimum of three locking points, with an anti-lift device to prevent them being lifted from their runners. Extra surface mounted patio locks can be fitted to provide additional security and reduce the leverage points.
- All ground floor windows and any windows that are easily accessible above ground floor should have key operated window locks, unless they are to be used as fire escapes.
- Window handles should be multi-locking, with shoot bolts into the frame. If not, surface mounted, key operated window locks should be fitted to provide additional security and reduce the leverage points.











Supporting you...

